




EASYSYSTEM®



YALTA

INSTALLATION AND MAINTENANCE



We thank you for having chosen EasySteam and appreciate your interest in our products.

Producing furnaces for Russian banyas we try to make them easy-to-use, long-lasting and safe to work with. Technical characteristics and design features of furnaces were tested in the conditions of Russian steam rooms which allows us to make a statement that «EasySteam»'s furnaces are made for true Russian banyas!

By installing the furnace made in "EasySteam" company in your family-owned steam room, you'll get the optimum correlation between the temperature and air humidity (microclimate) which will be perfect for you. Make your own Russian banya! Banya with its intrinsic pleasant warmth and easy steam!

For correct and safe furnace exploitation, read this instruction carefully!

Enjoy your bath,
"EasySteam" company

This document is protected by the Copyright Act, by the International Copyright Act and Intellectual Property Protection Acts and Agreements. No parts of this document may be reproduced or transmitted without the written permission of the authors!

Installation and all operating and maintaining activities should be performed after reading this manual.

Made in Russia



CONTENTS

04	—————	Product purpose
05	—————	Product description
08	—————	Furnace preparation for exploitation
11	—————	Assembly scheme for the protective cover
12	—————	Hot water production system
13	—————	Hot water production system
14	—————	Operation of hot water production system
15	—————	Installaton of hot water production system
16	—————	Assembly scheme for the veneer
17	—————	Furnace operation
19	—————	Overall dimentions of furnace
21	—————	Technical characteristics
22	—————	Configuration
23	—————	Transportation and storage
23	—————	Troubleshooting guide
24	—————	Guarantee obligations
25	—————	Equipment certificate




PRODUCT PURPOSE

Wood-burning furnace "Yalta" with an outer (open) and inner (closed) heaters is designed to heat up the sweating room, steam generation and hot water production. You will get as much easy steam as you want.

In order to use the furnace for other purposes, you need to have a written permission of the manufacturer. If the furnace is used for commercial purposes as well as if the furnace is burning for more than 10 hours, all guarantee obligations would be declared null and void and manufacturer will not be held liable for any potential adverse consequences.

PRODUCT DESCRIPTION



"EasySteam" company's furnaces are made from stainless heat-resistant steel with chrome content not less than 17%. The furnace body (point 1), which is 3 mm thick, is a complex bent-welded structure with additional elements to reinforce the construction. There are convection canals (point 2) on the outside of side-walls.

The protective heat-retaining shield (point 13), which is made of 2 mm thick construction steel, is installed around the furnace. The clearances between the wall of the furnace and protective cover are filled in with stones and make up an outer heater. A big amount of stones in the inner heater will keep the temperature within the design limits and will facilitate subsequent dehumidification of the sweating room.

Maintaining the flame temperature high inside the furnace is essential for the heating up of the inner heater (point 3) to the uttermost. There are protective heat-retaining shields (point 4) made of 20 mm chamotte tiles on the inner surface of the burner which help to redistribute the temperature load inside the furnace, significantly increase the heat energy transfer to the bottom of the heater and to take the load off the load-bearing wall.

The inner heater is a complex bent-welded reservoir made of 4 mm stainless steel in the center of the furnace.

In order to equally distribute the load of massive heater's filling, the heater's bottom is made semicircular that also lets to increase the heating area and to prevent the bottom elevated-temperature deformation. Maintenance of the equipment is done through the steam pipe (point 5).

Due to the fact that in the operating process the heater is one of the most loaded elements, total mass of the filling shouldn't exceed the maximum value mentioned in this manual!

Steam generating unit (point 6), which is a complex system of vertical and horizontal pipes, is installed in the heater to get high quality finely dispersed steam. Pin-holes are made in horizontal pipes to ensure even distribution of steam-water mixture over the most heated-up bottom layer of the heater's filling. The dispensing unit (point 7) is attached to the upper part of the steam generating unit. There is a safety (back pressure) valve in order to prevent an unpermitted emission of steam-water mixture in the opposite direction.

Before usage, it is necessary to check the performance capability of the dispensing unit. Remove (screw off) the dispensing unit and examine the safety valve. In case of discovering of foreign object (small pieces of bath besom or so on), remove them and wash the device properly.

Performance capability of the safety valve is checked by shaking if the valve is functional, you will hear a distinctive sound of valve jingling in both ways which indicates that nothing blocks its movement.

The boiler grate (point 8) is installed at the bottom of the furnace. Through the slots in the grate the air comes to the heater which is essential for high-temperature combustion process. Combustion products also get to the ash box (point 12) through the boiler grate.

At the top of the furnace there is a flue-gases outlet (point 9), a steam pipe (point 5), a pipe of a steam generating unit to connect it to the dispensing unit, and a cleanout port (point 14).

The cleanout port serves to clean and examine manufacturing clearances between the heater and the furnace body. Examine manufacturing clearances not less than once a year or when there is a difficulty of a chimney draft. In case if there is a lot of soot in the clearances, clear it off with a flexible brush for smoke pipes (pic.1). In order to get to cleanout port, ease off the cap nut on the lid of the cleanout port with a 13 mm wrench. While lifting the nut up, make three full rotations (don't unscrew the nut completely) then move the lid of the cleanout port aside and take it out of the port. Put the lid of the cleanout port back after the examination and tighten the cap nut.

The front of a furnace consists of a specially shaped frame with a door (point 11) and air governor (point 15) attached to it.

The front of a furnace and its body are separated by the fuel channel (point 10) which allows lighting the furnace from a room adjacent to the sweating one.

The furnace is painted with black organosilicone enamel.



Pic. 1 Flexible brush for smoke pipes

FURNACE PREPERATION FOR EXPOLOITATION

Before installation, you should test-light the furnace outdoors for 4-5 hours. During the first burning, all technical components (dirt, occupational dust and so on), which got on the furnace during the transportation and warehouse or production storage, will burn out.

Before putting the furnace into exploitation, make sure that all installation works were completed according to the requirements of this manual or to instructions for constituent parts made by other supplier!

When developing your banyas' project and installing the furnace, it is NECESSARY to ensure that all fire safety standards mentioned in the Code of Practice (CP) 112.13330.2011* "Fire safety of buildings and facilities" and CP 7.13130.2013 "Heating, ventilation and conditioning. Fire safety requirements. With Amendment No.1 & Amendment No.2" are met. Non-compliance with safety standards can cause a fire.

Furnace and chimney should be regularly checked. In case if there is any malfunction of the equipment, you should immediately stop exploiting the furnace and contact our specialists to get a troubleshooting assistance on a possible cause of this failure and remedial procedures to fix it.

Our main chimneys are made of stainless heat-resistant steel AISI 316 (310, 321) with wall thickness not less than 0.8 mm in the brick or stone veneer which is fixated with a decorative sheet (economizer).

The minimum distance between the cover and inflammable surfaces is 500 mm.

The protective heat-resisting shield in the front of the furnace should be as high as the full height of the room (pic 2).

While in operation the furnace has a thermal expansion of 3-5 mm. This should be taken into account in the process of installation.

It is prohibited to place the flue channel of the furnace outside. The furnace cannot be lighted up from the outdoors.

The pass-through in floors and in the roof should be made fire-proofed according to the CP 7.13130.2013. The floor in front of the door should be covered with a metal sheet in size of 700*500 mm in order to shield it from the combustible materials.

Combined extract-and-input ventilation is installed in the sweating room to insure good ventilation.

In the far corner away from the furnace, there is should be a small window under the ceiling to remove the carbon dioxide accumulated during the respiration.


The laying of the filling in the inner heater is done through the steam pipe at the top of the furnace. The laying of the filling in the outer heater is done through clearances between the cover and the wall.

Not every type of stone is suitable for the furnace! Undefined stones of unknown origin should not be used!

As the filling for the inner heater we recommend you to use following stones: gabbro-diabase, jadeite, quartzite, quartz, porphyrite, jasper and so on. They have high heat absorption capacity, don't contain any harmful impurities and won't be affected by changes of temperature. Before laying stones in the heater, clean them of any foreign particles and wash properly with hot water.

On the bottom of the heater, under the steam generating unit, lay stones of 100x80x70 mm fraction. Then it is recommended to lay bigger stones and fill up cavities with smaller fractions.

In order to avoid damaging the furnace, it is not recommended to make a monolithic-type laying of stones. You should always leave some space between the stones. Total mass of the filling shouldn't exceed the maximum value mentioned in this manual!



Pic. 2 Burner units' appearance


Burner units are installed in the burner and fixated with fasteners. For more detailed information on the installation, utilization and technical characteristics see the instructions for burner units.

The appearance of burners unit may differ from the one presented in the picture 2



Pic. 3 The passage for the combustion flue


ASSEMBLY SCHEME FOR THE PROTECTIVE COVER



Pic. 4 Assembly scheme for the protective cover

Side walls of the protective cover (point 1) are attached to legs (point 1) with screws (point 3). Put the assembled protective cover on the furnace (the cut-out notch should be placed on the flue chimney side). The clearances between the wall of the furnace and protective cover are filled in with stones (this makes up an outer heater). Then put boards (point 5) on the top. Lay stones on the top of the furnace.

HOT WATER PRODUCTION SYSTEM



STRUCTURE OF HOT WATER PRODUCTION SYSTEM

In the system of hot water production there are 2 main elements: heat-exchange unit (point 1) and water receiving tank (point 2) connected by pipes.

Heat-exchange unit is a rectangular tank with a volume of 3,5 liters. Its function is heating up of water by receiving heat of the furnace. The heat-exchange unit is attached directly to the side wall of the furnace. There are one inch threaded joints (points 3 and 4) on the top and on the bottom of the heat-exchange unit that connect pipe-lines to the side-mounted tank.

Heat-exchange unit is a structural section of the furnace. When the furnace is heated up, it is not allowed to fill up the system if there is no water in the water level gauge of the side-mounted water receiving tank.

Constant exploitation of the system without water is not permitted because it leads to short life of a furnace.

Side-mounted water receiving tank is a rectangular, cylindrical or different shape reservoir (shape and dimensions can vary based on customers wishes and technical peculiarities of the installation site). At the top of a tank there is a tank fillet pipe (point 5) which is needed to fill the system with water, with a hermetic lid (point 6) and one inch threaded joint (point 7) for steam removal from indoor space. There are one inch threaded inlet and outlet joints (points 8 and 9) at the bottom of a tank. The hot water faucet (point 10) is on the front wall of a tank. All water receiving tanks are equipped with water level gauges which allow monitoring water level while in operation.

Fill the tank with water not exceeding upper point of the water level gauge.

The heat-exchange unit and water receiving tank are connected by metal pipes (points 11 and 12) one inch in diameter. There is a T-tube (point 13) with connected discharge pipe on the bottom tube which allows discharging water system via faucet (point 14) in wintertime.

In circumstances when the distance between heat-exchange unit and water receiving tank is less than 1 metre, when water level lowers while in use or when the furnace burns for more than 3 hours, water can start boiling. Water boiling goes along with insignificant noise.

To prevent boiling add some cold water in the system (if water level lowers when in use).

Choose water receiving tank based on assumption that there's should be 15 litres per person plus 10 litres to steam the bath besom.

OPERATION OF HOT WATER PRODUCTION SYSTEM

To start the system, unscrew the lid and fill the tank with water.

Fill the system with water before lighting up the furnace. It's prohibited to fill the empty system when the furnace is hot!

When the furnace is burning, its walls release the heat, a significant part of which goes to the heat-exchange unit and heats up the water. The process of natural water circulation starts as a consequence of water temperature differences in heat-exchange unit and water receiving tank. Water from heat-exchange unit and water from water receiving tank start to mix up. The system starts to operate.

Open a faucet (point 10) on the front wall of the tank to get hot water.

Estimated time of water heating to the temperature of 80 degrees is between two and three hours and depends on layout of heat-exchange unit and water receiving tank connection as well as on their physical distance.

In case if there is a big distance between heat-exchange unit and water receiving tank or when the geometry of inlet pipes is complex, cut the low-power circulating pump into the system.

The process of system heating up is inevitably linked to a process of water evaporation. The higher water temperature in the system, the more intensive the process of evaporation. All generated steam should be removed from indoor space via exhaust steam pipe.

Exhaust steam pipe must be regularly examined before each burning of the furnace. For the purpose of your own safety and maintaining systems' working capacity, avoid pipes full or partial clogging.

To prevent breaks during winter, don't leave the water in the system!

INSTALLATION OF HOT WATER PRODUCTION SYSTEM

When installing the hot water production system, pay special attention to equipments' location. The heat-exchange unit should be placed in such a way to minimize the distance to water receiving tank and connect them in the most effective and practic way possible.

Water receiving tank should be placed in such a way that tanks' bottom surface would be not less than 100 mm higher than the top surface of the heat-exchange unit.

Maximum margin between the top surface of a heat-exchange unit and tanks' bottom surface should be not more than 2 meters. The water receiving tank is attached to the wall, in order to do that there are fasteners on the back wall of the tank.

Systems are connected via metal pipes and pipe branches. Avoid sagging of the connecting pipes, as they must be sloped from water receiving tank to heat-exchange unit.

Pipes connecting the heat-exchange unit and water-receiving tank should be free to move in places where they pass through the cover made of bricks or natural stones. The diameter of the passage in the cover made of bricks or natural stones should be 5-10 mm larger than the pipes coming out of the heat-exchange unit.

Connect water receiving tank and heat-exchange unit, avoiding unnecessary bends of connecting pipes.

Each additional bend of connecting pipes negatively affect the process of circulation.

You should only use high-temperature materials (flax fiber) as a seal for threaded connection joints of the heat-exchange unit.


To remove the steam from indoor space, connect the steam outlet joint to a pipe (hose) which removes the steam.

Place one end of the pipe (hose) somewhere where coming out steam would be safe for people around! When in use, watch carefully for the hose, so it doesn't have any bends!


For safe exploitation, tank should be covered with a wooden crate.

ASSEMBLY SCHEME FOR THE VENEER


- 1 Screw up the upper corner from the inside of the frame with 3 M4 nuts by use of 2.5 mm hex-nut wrench.



- 2 Screw up the left corner from the inside of the frame with 3 M4 nuts by use of 2.5 mm hex-nut wrench.



- 3 Screw up the right corner from the inside of the frame with 3 M4 nuts by use of 2.5 mm hex-nut wrench.



FURNACE OPERATION

Proper burning of the furnace significantly increases the service life and reduces a risk of fire breaking-out. A recommended heater's load is 50-70 % of its volume. The most appropriate fuel for the furnace is dry wood of deciduous hardwood trees (birches, aspens, alders). High quality fuel briquettes made of pressed sawdust may also be used.

It is prohibited to burn coal or peat in the furnace.

Before lighting the furnace, make sure that there are no combustion products left in the burner and ash box, clean them if needed.

To light a furnace, put a woodpile (3-5 logs) in the burner.

It is prohibited to light a furnace with highly inflammable liquids.

Log must not be longer than the length specified in the technical specifications! This could lead to smoking of the glass and overheating of the furnace portal.

Some time after firing up the furnace, an intensive combustion process starts, and high-temperature gases go up through manufacturing clearances between the heater and the furnace body as well as through the main chimney and engulf the heater in flames.

At the highest point high-temperature gases run against the top of the furnace and form a circle around the heater, in so doing, enhancing the heating-up of the inner filling.

Oxygen, that is essential for high-temperature combustion in the lower part of the heater, comes in directly through the boiler grate.

High-temperature combustion is a process directly connected with oxygen input, which is regulated by using the air governor.

Proper installation of main chimney prevents flue gases from getting into the room even if the furnace door is open.

Heating-up of the heater is directly connected to stones' (inner filling) heating-up.

When in service, walls of the furnace and the heater can undergo a slight deformation, which won't affect weld's leak-tightness. This is not a spoilage.

Well heated heater guarantees that you'll enjoy your easy steam!

In order to create true Russian banya temperature-humidity conditions in your sweating room, the furnace is installed with protective heat-retaining shields.


Protective shield absorbs direct radiation of heated furnace walls, prevents getting burns, makes outcoming warmth even more gentle and comfortable.

High quality steam is obtained by supplying water to the steam generating unit. From the dispensing unit water gets in horizontal pipes where preliminary preparation happens (water transforms into water-steam mixture). Then under the pressure, water-steam mixture comes out of small holes made along the whole length of horizontal pipes into the most heated layer of heater's filling. Going from the bottom up, water-steam mixture comes out of the steam pipe and fills the sweating room with an easy steam. Every stone (total volume of the filling) is involved in the steam production process, that why the steam comes out nothing else but finely dispersed (invisible) – easy! To get the steam you can also use stones of the outer filling.

Be careful! The process of water (volume of which is equal to one of the dispensing unit) transformation into the steam takes no longer than 5 seconds!

Chromium (Cr), as furnace compound, prevents oxygen combustion by metal surfaces of the furnace!


FURNACE DIMENTIONS



Pic. 5 Furnace dimentions

Furnace	Dimensions, mm						
	A	B	C	D	E	F	G
Yalta 15	920	805	760	605	490	403	466
Yalta 25	970	855	810	655	530	403	466
Yalta 35	1120	1005	810	655	530	433	536

Due to the constant improvement of furnaces' functionality and aesthetic qualities, structural design and dimensions could slightly differ from ones mentioned in this table. Chimney diameter of standard models of furnaces is 120 mm.



Pic. 6 Furnace dimentions

Furnace	Dimensions, mm				
	J	K	L	H (with ГГУ or САБК-ТБ burner unit)	J (with ГГУ or САБК-ТБ burner unit)
Yalta 15	450	370	255	-	-
Yalta 25	450	370	235	520	390
Yalta 35	520	390	235	520	390

TECHNICAL CHARACTERISTICS

Furnace		Yalta 15	Yalta 25	Yalta 35
The size of the heated space, M ³		10-20	20-30	30-40
Dimensions of the furnace with a protective cover				
Width, mm		490	530	530
Height, mm		920	970	1120
Depth, mm		760	810	810
Material	furnace	3-4 mm stainless heat-resistant steel		
	doors	steel, heat-resistant glass ceramic		
	boiler grate	stainless heat-resistant steel		
	protective cover	construction steel		
Type of a heater		closed internal heater, outer open heater		
Steam generating unit		built-in unit		
Supply of water		to the lower part		
Sweating room dehumidification		Yes		
Furnace lighting up from a room adjacent to the sweating one		Yes		
Construction		bent-welded structure		
Chimneys' diameter		120 mm		
Mass of the furnace (excluding the weight of stones filling and chamotte)		84 kg	96 kg	110 kg
Mass of the stones filling	Inner heater	40 kg	60 kg	80 kg
	Outer heater	200 kg	240 kg	280 kg
Time to enter "Russian banyas" mode (winter/summer)		110 min./ 80 min.		
Maximum log length		400 mm	450 mm	
Amount of consumable logs		5-12 kg/h	5-16 kg/h	10-20 kg/h
Size of a glass in the door (W – H)		370-370 mm		400-420 mm
Fuel type		firewood and/or natural gas		

Information on the type of fuel for your type of furnace is indicated in the "Product certificate" section on the page 25

CONFIGURATION

Equipment's delivery package consists of:

Wood-burning furnace with a built-in steam generating unit	1 pce
Protective cover with fasteners	1 set
Chamotte tiles*	1 set
Door*	1 pce
Ash box*	1 pce
Boiler grate*	1 pce
Dispensing unit (water supply)	1 pce
Lid of the dispensing unit	1 pce
Lid of the heater	1 pce
Installation and operation manual (product certificate)	1 copy

* - may be absent depending on the furnace type

Depending on the transportation mode and declared storage conditions, the manufacturer has a right to singly choose the packaging. All component parts are wrapped in a soft packaging and placed inside the furnace.

TRANSPORTATION AND STORAGE

The furnace can be transported by any means of transportation as long as conditions mentioned on the marking are observed.

The furnace should be stored indoors in the original packaging.

TROUBLESHOOTING GUIDE

Failure	Cause of a failure	Remedial procedure
Abnormality in the combustion process	<ol style="list-style-type: none">1 Air deficiency in the heater2 Difficulty of a chimney draft	<ol style="list-style-type: none">1 Clean the ash box2 Clean the chimney
Smell of smoke	<ol style="list-style-type: none">1 Difficulty of a chimney draft2 Insufficient leak-tightness of the chimney3 Chimneys' deterioration	<ol style="list-style-type: none">1 Clean the chimney2 Check and seal up chimneys' joints3 Replace the chimney
It is difficult to light up the furnace	Draft difficulty	Clean the chimney
Water doesn't get to the steam generating unit	Back-pressure valve is clogged	Take off and unclog the dispensing funnel
The safety valve doesn't work	Foreign object in the back-pressure valve	Take off and unclog the dispensing funnel
Outgoing vapor has a specific smell	<ol style="list-style-type: none">1 Poor-quality stones2 Old stones	<ol style="list-style-type: none">1 Replace stones and clean the heater2 Replace stones and clean the heater

In case if any malfunctioning has been detected, you should immediately stop exploiting the furnace and contact our specialists to get a troubleshooting assistance on a possible cause of this failure and remedial procedures to fix it.

GUARANTEE OBLIGATIONS

When the product is used in violation of rules which are set forth in this document, the manufacturer disclaims all warranty liabilities.

Warranty goes into effect as from the moment of furnace sale and provided only in the presence of the product certificate.

In case if there is no sale date in the certificate, the warranty period starts from the date of production but not more than 3 years.

Manufacturer provides furnace walls burn-out guarantee for 3 years:

This warranty doesn't cover detachable parts, furnace parts (chamotte tiles, boiler grate, glass, cords), paint-and-lacquer coating as well as damages in the course of incorrect installation or exploitation. If chamotte tile breaks inside the burner it will not affect the operation of the furnace and consequently this is not a warranty case.

Manufacturer disclaims all warranty liabilities upon any of the following:

- 1 Inappropriate use of the furnace
- 2 Commercial use of the furnace
- 3 Furnace exploitation with a natural stones veneer from another manufacturer, laying of the
- 4 Expiration of a warranty
- 5 Independent repair or changes in the engineering design of the furnace
- 6 Installation of gas equipment in the furnace, which is not designed for gas. Product certificate should contain information that the furnace could be used with gas equipment (page 25)
- 7 Installation of burner units unauthorized by manufacturer
- 8 Addition of different kinds of salts and salt-containing solutions without the use of a special device - evaporator

In case if a failure occurs, customer has the right to turn to an authorized distributor who sold the furnace or directly to the manufacturer.

When applying to distributor or manufacturer, provide installation and operation manual with filled-in product certificate. If you have any questions, please contact us by calling the toll-free number 8(800)555-56-16 or by using an e-mail: info@easystem.ru.



EASYSYSTEM[®]